



# DES-4121<sup>Q&As</sup>

PowerEdge Specialist Exam for Implementation Engineer

**Pass EMC DES-4121 Exam with 100% Guarantee**

Free Download Real Questions & Answers **PDF** and **VCE** file from:

<https://www.pass4itsure.com/des-4121.html>

100% Passing Guarantee  
100% Money Back Assurance

Following Questions and Answers are all new published by EMC  
Official Exam Center

-  **Instant Download** After Purchase
-  **100% Money Back** Guarantee
-  **365 Days** Free Update
-  **800,000+** Satisfied Customers



**QUESTION 1**

A technician needs to initially configure a server from a bare metal condition in the following area. Processor settings  
Disk configuration iDRAC network settings

The technician can only reboot the server once to achieve these tasks.

Where should the technician configure these settings?

- A. PERC Configuration Utility and iDRAC Settings
- B. PERC Configuration Utility only
- C. System BIOS, iDRAC Settings, Device Settings
- D. Device and PXE Settings

Correct Answer: A

---

**QUESTION 2**

A server has six memory modules attached to each CPU Memory Optimizer mode is configured. The user now wants to have maximum protection for the memory but cannot afford to lose any memory space. What should the technician install/configure?

- A. Six additional memory modules matching the original Switch on Single Rank Spare Mode
- B. Six additional memory modules matching the original Switch to Memory Mirroring
- C. No additional memory Switch on Single Rank Spare Mode
- D. No additional memory Switch to memory Mirroring

Correct Answer: A

---

**QUESTION 3**

Eight new servers have arrived at a datacenter. All use static IP addresses for iDRAC. The technician needs to enable these servers to contact the DHCP server on the network to obtain new IP addresses.

What method can the technician use to quickly switch to DHCP?

- A. Reboot each server to enable DHCP default settings
- B. Boot into CTRL+S and change iDRAC settings to DHCP
- C. Use the LCD panel to input a new IP address
- D. Log in to the iDRAC and enable DHCP



Correct Answer: D

Reference <https://www.dell.com/support/article/pk/en/pkbsd1/sln306877/dell-poweredge-how-to-configure-the-idrac-9-and-the-lifecycle-controller?lang=en>

---

#### QUESTION 4

A technician needs to add a device to SupportAssist Enterprise. Policy requires that no additional software be installed on the server OS.

In addition to Username and Password, what information is required to add the device?

- A. IP address or hostname for the server OS
- B. IP address for Dell TechDirect
- C. IP address for OpenManage Server Administrator
- D. IP address or hostname for the iDRAC

Correct Answer: D

---

#### QUESTION 5

After a disk rebuild operation, a technician needs to configure the system so that the rebuild process happens faster in the future, even at the expense of slowing users down. How should the technician perform this task?

- A. Change the System Profile to Performance in the System BIOS Settings
- B. Change the Rebuild Rate in the System BIOS Settings
- C. Change the System Profile to Performance in the iDRAC GUI
- D. Change the Rebuild Rate from the iDRAC GUI

Correct Answer: C

[DES-4121 VCE Dumps](#)

[DES-4121 Exam Questions](#)

[DES-4121 Braindumps](#)