



H35-211^{Q&As}

HCIP-Access V2.5

Pass Huawei H35-211 Exam with 100% Guarantee

Free Download Real Questions & Answers **PDF** and **VCE** file from:

<https://www.pass4itsure.com/h35-211.html>

100% Passing Guarantee
100% Money Back Assurance

Following Questions and Answers are all new published by Huawei
Official Exam Center

- ⚙️ **Instant Download** After Purchase
- ⚙️ **100% Money Back** Guarantee
- ⚙️ **365 Days** Free Update
- ⚙️ **800,000+** Satisfied Customers



**QUESTION 1**

(single) Is the following description correct?

The level of the MA5600T alarm can be divided into five levels: critical, major, minor, warning, and cleared.

- A. True
- B. False

Correct Answer: A

QUESTION 2

(Radio) The downstream effective bandwidth of the GPON PON port is

- A. 2G
- B. 1.25G
- C. 2.5G
- D. 2.2G

Correct Answer: C

QUESTION 3

(single) Take the MA5600 as an example. If you need to analyze the faulty service and find faults through the performance statistics provided by the MA5600, which of the following commands should be used to query system performance statistics?

- A. huawei(config-if-SCU-0/7)#display port state 0
- B. huawei(config-if-SCU-0/7)#display port statistics 0
- C. huawei(config-if-SCU-0/7)#display port traffic 0
- D. huawei(config-if-SCU-0/7)#display port opticstate all

Correct Answer: B

QUESTION 4

On the U2000 network management, the oLT PON port LED is not green, indicating that the PON port is faulty.

- A. wrong
- B. Right



Correct Answer: A

QUESTION 5

(single) Is the following description correct?

If the fast leave function of a multicast user is enabled, you can get a better service experience when users switch channels.

A. True

B. False

Correct Answer: A

[Latest H35-211 Dumps](#)

[H35-211 PDF Dumps](#)

[H35-211 VCE Dumps](#)