



# HQT-4120<sup>Q&As</sup>

Hitachi Vantara Qualified Professional VSP G200 to VSP G800 Storage Installation

**Pass Hitachi HQT-4120 Exam with 100% Guarantee**

Free Download Real Questions & Answers **PDF** and **VCE** file from:

<https://www.pass4itsure.com/hqt-4120.html>

100% Passing Guarantee  
100% Money Back Assurance

Following Questions and Answers are all new published by Hitachi  
Official Exam Center

- ⚙️ **Instant Download** After Purchase
- ⚙️ **100% Money Back** Guarantee
- ⚙️ **365 Days** Free Update
- ⚙️ **800,000+** Satisfied Customers





### QUESTION 1

Which Interfacing software gets Installed in the Maintenance PC (MPC) on a VSP Gx00 system?

- A. Device Manager - Storage Navigator
- B. Hitachi Command Suite
- C. Block Element Manager
- D. Hitachi Command Director

Correct Answer: C

---

### QUESTION 2

What are two available methods to perform storage provisioning and configuration using RAID Manager/ CCI? (Choose two.)

- A. in-band using FC
- B. CU using the SVP
- C. Storage Navigator CLI
- D. out-of-band using TCP/IP

Correct Answer: BC

---

### QUESTION 3

Which two applications get installed with Hitachi Command Suite? (Choose two.) Choose 2 answers

- A. Storage Navigator
- B. Hitachi Device Manager
- C. Hitachi Replication Manager
- D. Hitachi Infrastructure Director

Correct Answer: B

---

### QUESTION 4

You need to attach a storage array as external storage on a VSP G600. What are two requirements? (Choose two.) Choose 2 answers

- A. port security enabled



- B. UVM license enabled
- C. Host Group mode set
- D. External storage

Correct Answer: BD

---

#### QUESTION 5

A customer wants to change a production RAID group from RAID 5 (7D+1P) to RAID 6 (6D+2P) on a VSP G600 during normal operations. They have just unmapped the LUNs from the channel ports.

What needs to be performed next?

- A. Parity groups must be deleted.
- B. The RAID level must be changed in Storage Navigator.
- C. The RAID level in the SVP Maintenance window must be changed.
- D. The RAID 5 group must be put into DRU mode in Storage Navigator.

Correct Answer: A

[Latest HQT-4120 Dumps](#)

[HQT-4120 Practice Test](#)

[HQT-4120 Exam Questions](#)