

HP2-T23^{Q&As}

Supporting Industry Standard Server Solutions

Pass HP HP2-T23 Exam with 100% Guarantee

Free Download Real Questions & Answers PDF and VCE file from:

https://www.pass4itsure.com/hp2-t23.html

100% Passing Guarantee 100% Money Back Assurance

Following Questions and Answers are all new published by HP Official Exam Center

- Instant Download After Purchase
- 100% Money Back Guarantee
- 365 Days Free Update
- 800,000+ Satisfied Customers



2024 Latest pass4itsure HP2-T23 PDF and VCE dumps Download

QUESTION 1

A customer has a ProLiant DL32Ce Gen8 server with a Smart Array B120i controller installed The customer wants to migrate from RAID 5 to RAID 6 for increased fault tolerance RAID 6 is not listed as an option in the ACU.

What is the matt likely reason that RAID 6 is not an option?

- A. The Smart Array B120i controller does not offer RAID 6
- B. The controller firmware must be upgraded
- C. The Smart Array Advanced Pack must be purchased
- D. The Smart Array BIOS is configured incorrectly

Correct Answer: A

QUESTION 2

HP standard warranties support HP hardware. What are HP Care Packs designed to support?

- A. Software
- B. Storage
- C. Business
- D. Network

Correct Answer: C

QUESTION 3

How many months is the support duration for a Service Pack for ProLiant versions release?

- A. 6
- B. 12
- C. 18
- D. 24

Correct Answer: B

QUESTION 4

Which step must be performed after the system board is replaced on a ProLiant BL460c G8 server blade?

VCE & PDF Pass4itSure.com

https://www.pass4itsure.com/hp2-t23.html

2024 Latest pass4itsure HP2-T23 PDF and VCE dumps Download

- A. Enable ASR.
- B. Re-enter the serial number.
- C. Clear the NVRAM.
- D. Reconfigure the array.

Correct Answer: B

QUESTION 5

Which software tool should you use to deploy an operating system to a ProLiant BL460c Gen8 server blade?

- A. System Management Homepage
- B. Array Configuration Utility
- C. SmartStart
- D. Intelligent Provisioning

Correct Answer: D

QUESTION 6

Microsoft Windows BitLocker Encryption feature uses a TPM microcontroller chip to store certificates and encryption keys on a DL380 G7.

Which action must a field engineer perform before upgrading server firmware and installing an additional storage controller?

- A. Create new certificates and encryption keys.
- B. Disable BitLocker.
- C. Delete certificates and encryption keys.
- D. Disable TPM.

Correct Answer: B

QUESTION 7

Which statement describes the features of Service Pack for ProLiant (SPP)?

- A. SPP is a combination of the PSPs and the HP SmartUpdate Firmware DVD.
- B. SPP requires configuration through RBSU.
- $\ensuremath{\text{C.}}$ SPP is the replacement for the Service and Diagnostics tools.



2024 Latest pass4itsure HP2-T23 PDF and VCE dumps Download

D. SPP is supported only on servers running a Windows operating system.

Correct Answer: C

QUESTION 8

What can an engineer use to ensure quick, precise, intelligent installation when installing CPUs in a ProLiant Gen8 server?

- A. HP Intelligent Provisioning
- B. HP Smart Socket Guide
- C. HP Hot Plug CPU Sockets
- D. HP CPU Slot Isolation

Correct Answer: B

QUESTION 9

A customer has a ProLiant DL380p Gen8 server with one CPU and four 16 GB RDIMMs with 24 total DIMM slots. The customer wants to increase the memory in this server.

Which memory option is valid?


- A. Remove the existing memory and populate all memory slots with UDIMM memory.
- B. Populate the remaining 20 memory slots with additional UDIMM memory.
- C. Populate another eight memory slots with additional RDIMM memory.
- D. Populate the remaining 20 memory slots with additional RDIMM memory.

Correct Answer: C

QUESTION 10

A support engineer is installing DIMMs of different speeds and voltages in a ProLiant DL380p Gen8 Server. Which rules for DIMM installation must the engineer follow during this installation?

2024 Latest pass4itsure HP2-T23 PDF and VCE dumps Download



- A. Four quad-ranked LRDIMMs are supported across all memory channels. The server balances capacity automatically.
- B. RDIMMs operating at either 1.35V or 1.5V may be mixed in any order. The system will operate at the lower voltage.
- C. DIMMs of different speeds may be mixed in any order. The server will select the lowest common speed.
- D. UDIMMs, RDIMMs, and LRDIMMs may be mixed in the same bank in the server if only one processor is installed.

Correct Answer: BC

QUESTION 11

An administrator installed HP CS Platinum/Platinum Plus Power Supplies in an enclosure with ProLiant server blades.

Which additional components does the administrator need in order to track power usage and automate server discovery in the enclosure?

- A. HP iPDU and HP Power Regulator
- B. HP Insight Control and RBSU
- C. HP iPDU and HP Remote Support
- D. HP iPDU and HP Insight Control

Correct Answer: D

QUESTION 12

You are troubleshooting a problem with a ProLiant BL460c Gen8 server and need a report detailing the firmware and driver revisions on the server. Which report should you obtain?

A. iLO Event Logs

2024 Latest pass4itsure HP2-T23 PDF and VCE dumps Download

- B. Array Diagnostics Report
- C. Integrated Management Log
- D. Active Health Logs

Correct Answer: B

QUESTION 13


Which RAID level is known as Advance Data Guarding (ADG)?

- A. RAID 1
- B. RAID 5
- C. RAID 6
- D. RAID 10

Correct Answer: C

QUESTION 14

A support engineer is troubleshooting a ProLiant DL360p Gen8 server. A hard disk m a four drive RAID 5 set has failed. The engineer notices that on three of the drives, the LEO labeled D on the exhibit is on. What does the condition indicate?



A. Hot swapping of the failed drive is not supported in this condition

B. The LED indicates failure and predictive failure alerts. Two additional drives in the RAID set are at risk of failing and need to be replaced



https://www.pass4itsure.com/hp2-t23.html 2024 Latest pass4itsure HP2-T23 PDF and VCE dumps Download

- C. The drives should not be removed when this LED is illuminated
- D. The drive failure has corrupted three drives in the RAID set. The array must be rebuilt and data restored from backup

Correct Answer: C

QUESTION 15

What happens when you mix low-reduced DIMMs (LRDIMM) and unbuffered DIMMs (UDIMM)?

- A. The server blade will not boot up.
- B. The server blade boots up in safe mode.
- C. The server blade boots up normally if you do not mix the DIMMS in the same bank.
- D. The server blade boots up in a loop mode.

Correct Answer: C

HP2-T23 PDF Dumps

HP2-T23 VCE Dumps

HP2-T23 Practice Test