DC0-200^{Q&As}

Certified Server Professional Exam

Pass Dell DC0-200 Exam with 100% Guarantee

Free Download Real Questions & Answers **PDF** and **VCE** file from:

https://www.pass4itsure.com/dc0-200.html

100% Passing Guarantee
100% Money Back Assurance

Following Questions and Answers are all new published by Dell Official Exam Center

⚙ **Instant Download** After Purchase

⚙ **100% Money Back** Guarantee

⚙ **365 Days** Free Update

⚙ **800,000+** Satisfied Customers

QUESTION 1

What is included in the RAID enabler kit? (Choose three.)

A. cache memory

B. cache battery

C. cooling fan

D. SCSI cable

E. RAID key

Correct Answer: ABE

QUESTION 2

Which statement is true about using the Save feature of BASP?

A. It is used to install and configure the Broadcom Ethernet Controller driver.

B. It lets you transfer teaming configurations to other servers.

C. It is only available in Windows 2000.

D. It saves a configuration as an executable file.

Correct Answer: B

QUESTION 3

Which command line syntax assigns asset tag 12345 to a PowerEdge server using the Asset Tag Utility?

A. asset /d 12345

B. asset /s 12345

C. asset /c 12345

D. asset /r 12345

E. asset 12345

Correct Answer: E

QUESTION 4

A failed processor is removed on a quad processor system using slotted processors. The server displays video but the

POST halts and displays a "processor or terminator card not installed" error. The removed processor was in the third slot. What is needed to allow the system to complete POST and boot the OS?

A. press F2 for system setup and disable processor 3 in the BIOS

B. install a terminator card in processor slot 3

C. install the ISA_CLR jumper, go through POST, power off, and remove the jumper

D. move the terminator card from processor slot 4 to processor slot 3

Correct Answer: B

QUESTION 5

What type of security authentication scheme is used by OMSA under Windows 2000?

A. NTLM

B. SNMP

C. NDS

D. PAM

Correct Answer: A

QUESTION 6

You received an e-mail that states that a server has a warning on Fan 1. How can you determine the server status using Server Administrator? (Choose two.)

A. using telnet , log into the server and enter the status command to display the fan states

B. using OMSA, from the system tree find the fan that displays an exclamation point

C. using the Server Console, drill down to the fan to display the states

D. use an OMSA CLI command to display the status of Fan 1

Correct Answer: BD

QUESTION 7

Which two Dell servers are rack dense optimized? (Choose two.)

A. PowerEdge 2600

B. PowerEdge 1655MC

C. PowerEdge 1600SC

D. PowerEdge 1750

Correct Answer: BD

QUESTION 8

What is required to enable a management application such as Dell OpenManage IT Assistant to receive SNMP traps from Dell OpenManage Server Agent/Server Administrator?

A. You configure the SNMP service on the computer on which OpenManage IT Assistant is running (the management station) to the correct read community name so that it can read the traps correctly .

B. You configure the SNMP service trap destinations on the computer on which Dell OpenManage Server Administrator is running to send traps to the management station (where OpenManage IT Assistant is running).

C. You make sure OpenManage IT Assistant has discovered the managed node running Dell OpenManage Server Administrator.

D. Nothing needs to be done. OpenManage IT Assistant automatically registers to receive traps when it discovers the managed node on which Dell OpenManage Server Administrator is running.

Correct Answer: B

QUESTION 9

A PowerEdge server contains 8 GB of memory. During the POST sequence, only 256 MB is shown.

What is the most likely problem?

A. The memory card is in Safe Mode.

B. The memory card needs to be reseated.

C. There is a PERC card installed.

D. The processor stepping is mismatched.

E. OS Install Mode is enabled in the System Setup.

Correct Answer: E

QUESTION 10

Which two components can be installed in the 0U space found in Dell racks? (Choose two .)

A. Dell Dual-Power Grid Switch

B. Dell flat panel monitor

C. Dell UPS

D. Dell PDU

Correct Answer: AD

QUESTION 11

Which OpenManage component is the central repository for asset and inventory information?

A. Array Manager

B. Server Agent

C. DRAC II Web Console

D. IT Assistant

Correct Answer: D

QUESTION 12

Click the Exhibit button. In Red Hat Linux, which network command produces the o utput shown in the exhibit ?

A. netconfig -r

B. netstat -s

C. ifconfig -a

D. ipconfig

Correct Answer: C

QUESTION 13

You have just installed W2K on your server and you cannot get the server to see your local network. What can you do to diagnose network connectivity? (Choose three.)

A. verify that the subnet address is the same as the rest of the working devices on your LAN

B. verify that if attached to a switch and using VLANs, your port is in the proper configuration

C. verify that the server is configured to use DNS

D. verify that the cable plugged into your server is not a cross-over cable

Correct Answer: ABD

QUESTION 14

When you create a logical drive using the Create Volume Wizard, the logical drive size is prefilled on the Select Partition Type screen. What does this logical drive size indicate?

A. the minimum logical drive size that can be created on that drive

B. the suggested logical drive size that should be created on that drive

C. the maximum logical drive size that can be created on that drive

D. the logical drive size from the previously created logical drive

Correct Answer: C

QUESTION 15

Which three statements are true for the OpenManage IT Assistant inventory page? (Choose three.)

A. The number of columns that can be selected at any one time on the inventory page is limited to ten.

B. The inventory page reports the status of a system.

C. Inventory items in the inventory page for a discovered system are updated upon each discovery round.

D. The inventory page supports printing to a printer.

E. The inventory page is sortable by any column.

Correct Answer: CDE

[DC0-200 PDF Dumps](#)   [DC0-200 VCE Dumps](#)   [DC0-200 Practice Test](#)