

E20-393^{Q&As}

Unity Solutions Specialist Exam for Implementation Engineers

Pass EMC E20-393 Exam with 100% Guarantee

Free Download Real Questions & Answers PDF and VCE file from:

https://www.pass4itsure.com/e20-393.html

100% Passing Guarantee 100% Money Back Assurance

Following Questions and Answers are all new published by EMC
Official Exam Center

- Instant Download After Purchase
- 100% Money Back Guarantee
- 365 Days Free Update
- 800,000+ Satisfied Customers



2024 Latest pass4itsure E20-393 PDF and VCE dumps Download

QUESTION 1

What is the first step to configure asynchronous replication for a storage resource?

- A. Set up management channel
- B. Configure replication session
- C. Verify replication connection
- D. Create replication interfaces

Correct Answer: D

QUESTION 2

Which Dell EMC Unity model(s) supports the 12 Gb/s SAS I/O module?

- A. All Dell EMC Unity models
- B. Dell EMC Unity 600/650F only
- C. Dell EMC Unity 500/550F and Dell EMC Unity 600/650F only
- D. Dell EMC Unity 400/450F, Dell EMC Unity 500/550F, and Dell EMC Unity 600/650F only

Correct Answer: C

Reference: https://www.dellemc.com/resources/en-us/asset/white-papers/products/storage/h15084-dell_emc_unity-introduction_to_the_platform.pdf (14)

QUESTION 3

What is the default NFS host access option?

- A. No Access
- B. Read/Write, Allow Root
- C. Read-Only
- D. Read/Write

Correct Answer: B

Reference: https://www.emc.com/collateral/TechnicalDocument/docu69323.pdf (11)

QUESTION 4



2024 Latest pass4itsure E20-393 PDF and VCE dumps Download

What is a consideration when attempting to downgrade from Integrated ESRS Two-way to ESRS One-way?

- A. Ensure that port 9443 is open
- B. Validate Dell EMC Support Credentials
- C. Run readiness check prior to downgrading ESRS
- D. Downgrading ESRS is not supported

Correct Answer: D

QUESTION 5

When configuring integrated ESRS access to a Dell EMC Unity XT array, which firewall ports need to be open?

- A. 443 and 8443
- B. 443 and 9443
- C. 8443 and 9443
- D. 22 and 8443

Correct Answer: A

Reference: https://www.dellemc.com/tr-tr/documentation/unity-family/unity-p-cli-user-guide/02-unity-cli-br-manage-the-system.htm

QUESTION 6

What is the usefulness of setting a quota limit to zero?

- A. Increases space efficiency on the file system.
- B. Reduces CPU overhead for clients accessing data.
- C. Increases file system access performance.
- D. Enables tracking and reporting on file system usage.

Correct Answer: D

QUESTION 7

What is the size of a Private LUN slice?

- A. 8 KB
- B. 64 KB



2024 Latest pass4itsure E20-393 PDF and VCE dumps Download

C. 256 MB

D. 1024 MB

Correct Answer: C

Reference: https://www.dellemc.com/resources/en-us/asset/white-papers/products/storage/h16289-dell_emc_unity-

 $dynamic_pools.pdf$

QUESTION 8

A service provider is installing a Unity storage system for an end-user. The end-user is concerned about network security and will not allow the service provider access to the network.

How can the service provider set a static IP address for the Unity storage system management interface?

- A. Use the embedded InitCLI tool
- B. Connect directly to the service ports and configure the networking through UEMCLI
- C. Use an IPMI serial over LAN connection
- D. Use the Connection Utility to create a configuration file

Correct Answer: B

The svc_initial_config UEMCLI command sets up initial system configuration. It configures a management IP address when the Connection Utility (CU) is not available on the network. If an address is set, this command can also change the management IPv4 and IPv6 configuration mode. It attempts to configure the system with the given friendly name and/or network parameters.

Note: The Unisphere CLI (UEMCLI) is a tool that provides us with the CLI access to perform the same actions as one would on the Unisphere web interface.

References: https://www.emc.com/collateral/TechnicalDocument/docu69328.pdf (page 60)

QUESTION 9

During the configuration of ESRS, how is the Customer Contact Data verified?

- A. Access code sent through email to the customer
- B. Step taken during the ESRS Network check
- C. Step taken by the ESRS Policy Manager
- D. Step taken during the readiness check for ESRS

Correct Answer: A

QUESTION 10

VCE & PDF Pass4itSure.com

https://www.pass4itsure.com/e20-393.html

2024 Latest pass4itsure E20-393 PDF and VCE dumps Download

A Thin Clone has just been created. What operation can be performed on it?
A. Change FAST VP Policy
B. Change SP ownership
C. Change Data Reduction setting
D. Increase its size.
Correct Answer: D
Reference: https://www.dellemc.com/resources/en-us/asset/white-papers/products/storage/h15089-dell-emc-unity-snapshots-and-thin-clones.pdf (27)
QUESTION 11
What is the maximum number of LUN snapshots that are supported by Unity?
A. 16
B. 96
C. 256
D. 512
Correct Answer: C
Note: Logical Unit Number (LUN) ?A block-level storage device that can be accessed using a protocol such as iSCSI.
QUESTION 12
Which storage access configuration is unique to VMware Datastores?
A. Host IO burst policy
B. vCenter Server
C. IP Multi-tenancy
D. Auto formatting
Correct Answer: C

QUESTION 13

What pathing options are supported by Dell EMC Unity XT systems to provide a host with Fibre Channel access to block storage?

A. Single Path, Multipath, and Alternate Path



2024 Latest pass4itsure E20-393 PDF and VCE dumps Download

- B. Single Path and Multipath only
- C. Multipath only
- D. Single Path only

Correct Answer: B

Reference: https://www.dellemc.com/zh-tw/collaterals/unauth/technical-guides-support-information/products/storage/docu69325.pdf

QUESTION 14

A storage administrator wants to asynchronously replicate a compressed LUN from the primary site to a Unity at the secondary site. Which statement describes this operation?

- A. Replication of compresses data is controlled by the bandwidth throttle setting.
- B. By default, replication compresses data sent to the destination.
- C. The source data is uncompressed, then replicated to the destination.
- D. The source data is replicated to the destination, then uncompressed.

Correct Answer: D

QUESTION 15

When can a LUN be defined as thin or thick?

- A. Any time after the LUN has been created
- B. Only when creating the LUN
- C. Only when enabling data reduction on the LUN
- D. Only when adding host access to the LUN

Correct Answer: B

Reference: https://community.emc.com/docs/DOC-24278

E20-393 Study Guide

E20-393 Exam Questions

E20-393 Braindumps