



# HP2-T23<sup>Q&As</sup>

Supporting Industry Standard Server Solutions

**Pass HP HP2-T23 Exam with 100% Guarantee**

Free Download Real Questions & Answers **PDF** and **VCE** file from:

<https://www.pass4itsure.com/hp2-t23.html>

100% Passing Guarantee  
100% Money Back Assurance

Following Questions and Answers are all new published by HP Official Exam Center

-  **Instant Download** After Purchase
-  **100% Money Back** Guarantee
-  **365 Days** Free Update
-  **800,000+** Satisfied Customers



**QUESTION 1**

How wide must the a data center door be to allow an HP MCS G2 rack to be brought into the data center?

- A. 45 cm (1.5 feet)
- B. 60 cm (2 feet)
- C. 80 cm (2.5 feet)
- D. 110 cm (3.6 feet)

Correct Answer: D

---

**QUESTION 2**

How can you verify that the system and option ROMs in a ProLiant server are the latest version?

- A. Review the information in the Insight Display
- B. Launch the Intelligent Management Center and view updates.
- C. Restart the server and review ORCA
- D. Restart the server and review POST.

Correct Answer: A

---

**QUESTION 3**

You need to capture the configuration and support dump of several Virtual Connect domains. Which tool can you use to perform this action from a central system?

- A. Insight Control
- B. HP Systems Insight Manager (HP SIM)
- C. Virtual Connect Enterprise Manager (VCEM)
- D. Virtual Connect Support Utility (VCSU)

Correct Answer: D

---

**QUESTION 4**

Which feature should you enable in RBSU in a ProLiant Gen8 server lo reduce processor power usage and improve overall performance in some applications?

- A. OS Control Mode



- B. Processor Core Disable
- C. Intel Hyper-Threading
- D. HP Dynamic Power Savings Mode

Correct Answer: B

---

#### QUESTION 5

Which type of memory is used on the HP Smart Array controller cache?

- A. RDRAM
- B. DRAM
- C. SRAM
- D. SDRAM

Correct Answer: B

---

#### QUESTION 6

A customer has a ProLiant DL380p Gen8 server with one CPU and four 16 GB RDIMMs with 24 total DIMM slots. The customer wants to increase the memory in this server.

Which memory option is valid?

- A. Remove the existing memory and populate all memory slots with UDIMM memory.
- B. Populate the remaining 20 memory slots with additional UDIMM memory.
- C. Populate another eight memory slots with additional RDIMM memory.
- D. Populate the remaining 20 memory slots with additional RDIMM memory.

Correct Answer: C

---

#### QUESTION 7

What is a DDR3 memory population rule to follow for a ProLiant Gen8 server?

- A. UDIMMs, RDIMMs, and LRDIMMs can be mixed in the same bank.
- B. DIMMs of different voltages or speeds cannot be mixed in the same bank.
- C. If only one processor is installed in a two-processor system, only half of the DIMM slots are available.
- D. The server automatically balances capacity of quad-rank RDIMMs across all memory channels.



Correct Answer: A

---

#### QUESTION 8

Which steps should you perform to save a Virtual Connect configuration?

- A. From CLI show all > cfg.txt
- B. Enclosure setting configuration scripts show, config save
- C. Enclosure setting configuration scripts inventory
- D. VCM Tools Backup/Restore Domain Configuration

Correct Answer: D

---

#### QUESTION 9

Which Onboard Administrator GUI virtual power button command powers the server on and off gracefully?


- A. Momentary press
- B. Restart
- C. Reset
- D. Press and hold

Correct Answer: A

---

#### QUESTION 10

A support engineer is installing DIMMs of different speeds and voltages in a ProLiant DL380p Gen8 Server. Which rules for DIMM installation must the engineer follow during this installation?



- A. Four quad-ranked LRDIMMs are supported across all memory channels. The server balances capacity automatically.
- B. RDIMMs operating at either 1.35V or 1.5V may be mixed in any order. The system will operate at the lower voltage.
- C. DIMMs of different speeds may be mixed in any order. The server will select the lowest common speed.
- D. UDIMMs, RDIMMs, and LRDIMMs may be mixed in the same bank in the server if only one processor is installed.

Correct Answer: BC

#### QUESTION 11


Which Customer Service Repair (CSR) category allows a customer to have HP replace a failed part under warranty at no additional charge?

- A. CSR Advance Unit Replacement
- B. CSR mandatory
- C. CSR express
- D. CSR optional

Correct Answer: D

#### QUESTION 12

A support engineer is troubleshooting a ProLiant DL360p Gen8 server. A hard disk in a four drive RAID 5 set has failed. The engineer notices that on three of the drives, the LEO labeled D on the exhibit is on. What does the condition indicate?



- A. Hot swapping of the failed drive is not supported in this condition
- B. The LED indicates failure and predictive failure alerts. Two additional drives in the RAID set are at risk of failing and need to be replaced
- C. The drives should not be removed when this LED is illuminated
- D. The drive failure has corrupted three drives in the RAID set. The array must be rebuilt and data restored from backup

Correct Answer: C

### QUESTION 13

What are two standard features of the HP Modular Cooling System G2? (Select two.)

- A. Phone-home capability of a failing component
- B. Non hot-swappable high-airflow fans
- C. Support for two racks simultaneously
- D. Use of bi-directional cooling

Correct Answer: CD

### QUESTION 14

Which RAID level allows the data to be striped across multiple RAIDs? (Select two.)

- A. RAID 0
- B. RAID 1



- C. RAID 5
- D. RAID 50
- E. RAID 60

Correct Answer: AD

---

#### QUESTION 15

How do you boot into Intelligent Provisioning on a ProLiant Gen8 server?

- A. By pressing the F9 button during POST
- B. By pressing the F10 button during POST
- C. Through a Scripting Toolkit server configuration script
- D. Through the Array Configuration Utility (ACU) in offline mode

Correct Answer: B

[HP2-T23 PDF Dumps](#)

[HP2-T23 Exam Questions](#)

[HP2-T23 Braindumps](#)