# H13-341 Q&As

Huawei Certified internetwork Expert - Transmission

## Pass Huawei H13-341 Exam with 100% Guarantee

Free Download Real Questions & Answers **PDF** and **VCE** file from:

**https://www.pass4itsure.com/h13-341.html**

100% Passing Guarantee
100% Money Back Assurance

Following Questions and Answers are all new published by Huawei Official Exam Center

- **Instant Download** After Purchase
- **100% Money Back** Guarantee
- **365 Days** Free Update
- **800,000+** Satisfied Customers

**QUESTION 1**

When creating new NE, which of the following Configuration Mode can be selected?

A. Initialize and Manually Configure NE Data

B. Download

C. Upload

D. Copy NE Data

Correct Answer: D

**QUESTION 2**

Which of the following residual dispersion values are within the dispersion tolerance of the TN52ND2 board?

A. 900ps/nm

B. 500ps/nm

C. 700ps/nm

D. 600ps/nm

Correct Answer: C

**QUESTION 3**

Which of the following statements about the electrical-layer overhead processing source function are correct?

A. The OPUk performs client signal mapping, frequency adjustment, and rate adaptation in the transmit direction.

B. The ODUkT calculates the BIP-8 and writes it into the TCMi.

C. The OTUk calculates BIP-8 and writes it into SM, GCC0, FAS, and MAFS.

D. the ODUkP calculates overheads such as BIP-8, PM, and GCC1/2.

Correct Answer: C

**QUESTION 4**

The causes of discrete services are as follows:

A. The cross-connection configuration on the NE is incorrect.

B. The logical fiber connection of the NE is inconsistent with the physical fiber connection.

C. The configuration data on the NE side is not uploaded to the U2000.

D. A subnet service whose source or sink port is not in the management scope of the U2000 is available.

Correct Answer: D

**QUESTION 5**

For the MSTP equipment, the pass-through mode is used for VC-4 services by default, and the termination mode is used for VC12/VC3 services by default.

A. True

B. False

Correct Answer: B