



NSE6_FWF-6.4^{Q&As}

Fortinet NSE 6 - Secure Wireless LAN 6.4

Pass Fortinet NSE6_FWF-6.4 Exam with 100% Guarantee

Free Download Real Questions & Answers **PDF** and **VCE** file from:

https://www.pass4itsure.com/nse6_fwf-6-4.html

100% Passing Guarantee
100% Money Back Assurance

Following Questions and Answers are all new published by Fortinet
Official Exam Center

-  **Instant Download** After Purchase
-  **100% Money Back** Guarantee
-  **365 Days** Free Update
-  **800,000+** Satisfied Customers



**QUESTION 1**

Which two roles does FortiPresence analytics assist in generating presence reports? (Choose two.)

- A. Gathering details about on site visitors
- B. Predicting the number of guest users visiting on-site
- C. Comparing current data with historical records
- D. Reporting potential threats by guests on site

Correct Answer: AB

QUESTION 2

Which statement is correct about security profiles on FortiAP devices?

- A. Security profiles on FortiAP devices can use FortiGate subscription to inspect the traffic
- B. Only bridge mode SSIDs can apply the security profiles
- C. Disable DTLS on FortiAP
- D. FortiGate performs inspection the wireless traffic

Correct Answer: B

Reference: <https://docs.fortinet.com/document/fortiap/6.4.0/fortiwifi-and-fortiap-configuration-guide/47321/fortiap-s-bridge-mode-security-profiles>

QUESTION 3

Which factor is the best indicator of wireless client connection quality?

- A. Downstream link rate, the connection rate for the AP to the client
- B. The receive signal strength (RSS) of the client at the AP
- C. Upstream link rate, the connection rate for the client to the AP
- D. The channel utilization of the channel the client is using

Correct Answer: B

SSI, or "Received Signal Strength Indicator," is a measurement of how well your device can hear a signal from an access point or router. It's a value that is useful for determining if you have enough signal to get a good wireless connection. Reference: <https://www.metageek.com/training/resources/understanding-rssi.html>



QUESTION 4

How can you find upstream and downstream link rates of a wireless client using FortiGate?

- A. On the FortiAP CLI, using the cw_diag ksta command
- B. On the FortiAP CLI, using the cw_diag -d sta command
- C. On the FortiGate GUI, using the WiFi Client monitor
- D. On the FortiGate CLI, using the diag wireless-controller wlac -d Sta command

Correct Answer: C

The WiFi Client monitor on the FortiGate GUI shows the upstream and downstream link rates of a wireless client, along with other information such as MAC address, SSID, IP address, signal strength, and connection time. The link rates indicate the maximum data rates that the client can achieve in both directions. References: Secure Wireless LAN Course Description, page 7; [FortiOS 6.4.0 Handbook - Wireless Controller], page 37.

QUESTION 5

When configuring a wireless network for dynamic VLAN allocation, which three IETF attributes must be supplied by the radius server? (Choose three.)

- A. 81 Tunnel-Private-Group-ID
- B. 65 Tunnel-Medium-Type
- C. 83 Tunnel-Preference
- D. 58 Egress-VLAN-Name
- E. 64 Tunnel-Type

Correct Answer: ABE

The RADIUS user attributes used for the VLAN ID assignment are:

IETF 64 (Tunnel Type)—Set this to VLAN.

IETF 65 (Tunnel Medium Type)—Set this to 802

IETF 81 (Tunnel Private Group ID)—Set this to VLAN ID.

Reference: <https://www.cisco.com/c/en/us/support/docs/wireless-mobility/wireless-vlan/71683-dynamicvlan-config.html>

[Latest NSE6_FWF-6.4 Dumps](#)

[NSE6_FWF-6.4 PDF Dumps](#)

[NSE6_FWF-6.4 Practice Test](#)